



JEWELRY SHOWCASE ASSEMBLY INSTRUCTION MANUAL



FRONT OF SHOWCASE



REAR OF SHOWCASE



STORE SUPPLY WAREHOUSE, LLC

PHONE : 1-800-823-8887


FAX : 1-800-823-0004

WWW.STORESUPPLY.COM


04212008

JEWELRY SHOWCASE ASSEMBLY INSTRUCTION MANUAL


RECOMMENDED TOOLS FOR ASSEMBLY



PHILLIPS SCREW DRIVER



PAIR OF PLIERS




RAZOR BLADE

HAMMER

HARDWARE AND MISC. INCLUDED: (PACKAGED IN A BAG)

NOTE: ALL ITEMS ARE SHOWN ACTUAL SIZE: IF YOU ARE NOT SURE WHICH PARTS IS CORRECT, THEN PLACE ON TOP OF ITEM BELOW FOR HELP DURING ASSEMBLY.



22 EA. - CAM LOCK PINS - 1 3/4" L FOR INSTRUCTION STEP 1




8 EA. - BLACK FOAM BLOCKS FOR INSTRUCTION STEP 4




6 EA. - SELF-STICKING SCREW COVERS SAME COLOR AS SHOWCASE


NOTE: THIS ARROW TIP MUST POINT TO THE HOLE FOR CAM LOCK PINS



22 EA. - 3/4" CAM LOCK CONNECTOR NUTS (CAM LOCK NUTS MAY ALREADY BE INSERTED INTO PANELS)




1 EA. - STANDARD FOOTPIECE




4 EA. - SELF-STICKING SCREW COVERS SAME COLOR AS SHOWCASE



28 EA. - WOOD DOWELS - 1 1/8" L FOR INSTRUCTION STEP 1



2 EA. - PAN HEAD SCREWS - 5/8" L FOR INSTRUCTION STEP 5




5 EA. - GREY GLAZING GASKETS FOR INSTRUCTION STEP 6




6 EA. - STEEL FLAT HEAD SCREWS - 1 1/4" L FOR INSTRUCTION STEP 6



1 EA. - STEEL FLAT HEAD SCREWS - 1" L FOR INSTRUCTION STEP 6



2 EA. - FOAM TAPE STRIPS PROVIDED IN A ROLL FOR INSTRUCTION STEP 7




2 EA. - DOWNTUBE HOLE CAP FOR INSTRUCTION STEP 7



JEWELRY SHOCASE ASSEMBLY INSTRUCTION MANUAL


PARTS INCLUDED INSIDE CARTON:



2 EA.
SLIDING DOOR PANELS




1 EA.
UPPER FRONT
GLASS TRACK




1 EA.
UPPER SLIDING
DOOR TRACK



1 EA.
TOP GLASS SUPPORT




1 EA.
UPPER DECK PANEL



2 EA.
END PANELS



1 EA.
TOP GLASS




1 EA.
FRONT PANEL

BOTTOM SLIDING DOOR
TRACK WILL BE ATTACHED



1 EA.
FRONT GLASS



1 EA.
LOWER DECK PANEL



UPPER DECK
SUPPORT



2 EA.
LOWER FRONT
AND BACK PANELS



JEWELRY SHOCASE ASSEMBLY INSTRUCTION MANUAL


ASSEMBLY TIME APPROXIMATELY 1 1/2 HOURS

WITH A HELPER

STEP 1 :

SCREW ONE 1 3/4" CAM LOCK PIN INTO EACH OF TEN HOLES AS INDICATED IN EACH OF THE END PANELS.
(SEE DIAGRAM "1A")

SCREW ONE WOODEN DOWEL INTO EACH OF THE TEN HOLES AS INDICATED IN EACH OF THE END PANELS.
(SEE DIAGRAM "1B")



TYP. END PANEL
(RIGHT END SHOWN)





DIAGRAM "1A"



STEP 1 - DIAGRAM "A"
SEE DIAGRAM "1A" FOR
LOCATION OF HOLES





DIAGRAM "1B"






STEP 1 - DIAGRAM "B"
SEE DIAGRAM "1B" FOR
LOCATION OF HOLES

JEWELRY SHOCASE ASSEMBLY INSTRUCTION MANUAL

STEP 2 :

INSERT IN ONE 3/4" CAM LOCK CONNECTOR NUT INTO EACH OF THE FOUR HOLES ON THE LOWER DECK PANEL, THE LOWER FRONT PANEL, AND THE LOWER BACK PANEL MAKING SURE THAT THE ARROWS FACE OUTWARD. SCREW ONE CAM LOCK CONNECTOR PIN INTO EACH OF THE TWO HOLES INDICATED ON THE BOTTOM OF THE LOWER DECK PANEL. (SEE DIAGRAM "2A")




JEWELRY SHOCASE ASSEMBLY INSTRUCTION MANUAL



STEP 3 :

LAY ONE END PANEL ON THE GROUND WITH THE DOWELS AND CAM LOCK PINS FACING UP. NOW INSERT THE LOWER DECK PANEL OVER THE END PANEL LINED UP WITH THE CAM LOCK PINS AND WOOD DOWELS IN THE END PANEL.(SEE DIAGRAM "3A") TIGHTEN DOWN THE CAM LOCK CONNECTOR NUTS.

ATTACH THE LOWER FRONT AND BACK PANELS IN THE SAME WAY.




MAKE SURE THAT CAM LOCK PINS AND WOOD DOWELS ARE IN-LINE BEFORE PUSHING DECK PANEL ON END PANEL.






JEWELRY SHOCASE ASSEMBLY INSTRUCTION MANUAL

STEP 4 :

INSERT ONE 3/4" CAM LOCK CONNECTOR NUT INTO EACH OF THE FOUR HOLES ON THE BACK OF THE FRONT PANEL AND TWO WOODEN DOWELS INTO THE HOLES ON THE BOTTOM OF THE FRONT PANEL. LOWER THE FRONT PANEL INTO PLACE AS INDICATED IN **DIAGRAM "4A"** MAKING SURE TO LINE UP THE CAM LOCK PINS AND DOWELS ON ALL SIDES. TIGHTEN THE CAM LOCK NUTS TO SECURE. INSERT TWO WOODEN DOWELS INTO THE UPPER DECK SUPPORT. GENTLY TAP THE UPPER DECK SUPPORT INTO THE TWO HOLES IN THE LOWER DECK PANEL. (**SEE DIAGRAM "4C"**)



MAKE SURE THAT CAM LOCK PINS AND WOOD DOWELS ARE IN-LINE BEFORE PUSHING DECK PANEL ON END PANEL.



JEWELRY SHOCASE ASSEMBLY INSTRUCTION MANUAL

STEP 5 :

INSERT FOUR 3/4" CAM LOCK CONNECTOR NUTS AND GENTLY TAP FOUR WOODEN DOWELS INTO EACH OF THE HOLES INDICATED IN DIAGRAM "5A". LOWER THE UPPER DECK PANEL INTO PLACE MAKING SURE TO LINE UP ALL CONNECTOR PINS AND WOODEN DOWELS. TAP THE UPPER DECK PANEL FLUSH WITH THE UPPER DECK SUPPORT AND TIGHTEN THE CAM LOCK CONNECTOR NUTS TO SECURE.

DIAGRAM "5A"





DIAGRAM "5B"



JEWELRY SHOCASE ASSEMBLY INSTRUCTION MANUAL

STEP 6 :

PLACE 6 BLACK FOAM SETTING BLOCKS INTO THE ROUTED GROOVE ON THE UPPER DECK PANEL (EVENLY SPACED) AND 2 FOAM SETTING BLOCKS INTO THE GROOVES IN THE ASSEMBLED END PANEL. **(REMOVE PAPER BACK ON FOAM SETTING BLOCK AND PLACE STICKY SIDE INTO GROOVE)** PLACE GLASS FRONT PANEL INTO GROOVES ON THE DECK AND END PANELS.. **(SEE DIAGRAM "6A")** NOW POSITION THE OTHER END PANEL ON TOP BY ALIGNING THE CAM LOCK PINS AND WOODEN DOWELS. **(SEE DIAGRAM "6B")** TIGHTEN THE CAM LOCK NUTS TO SECURE THE END PANEL.

DIAGRAM "6A"






DIAGRAM "6B"



FOAM SETTING BLOCKS
PEEL OFF PAPER BACK
PUT STICKY SIDE IN THE
GROOVE






DETAIL A



JEWELRY SHOCASE ASSEMBLY INSTRUCTION MANUAL

STEP 7 :






CAREFULLY TURN THE UNIT UPRIGHT (THIS MAY REQUIRE TWO PEOPLE). LINE UP THE STANDARD FOOTPIECE WITH THE PRE-DRILLED HOLES IN THE UPPER DECK AND ATTACH IT TO THE DECK USING THE 5/8" PAN HEAD SCREWS. (SEE DIAGRAM "7A") AFFIX THE GLAZING GASKETS SPACED EVENLY ACROSS THE TOP OF THE FRONT GLASS PANEL. (SEE DIAGRAM "7B")



JEWELRY SHOWCASE ASSEMBLY INSTRUCTION MANUAL

STEP 8 :

LINE UP THE UPPER SLIDING DOOR TRACK WITH THE SCREW HOLES IN THE END PANELS. ATTACH TRACK USING 1 1/4" STEEL FLAT HEAD SCREWS FROM THE OUTSIDE FACE OF THE END PANEL. (SEE DIAGRAM "8A") PLACE THE UPPER FRONT GLASS TRACK ON TOP OF THE GLAZING GASKETS AND FRONT GLASS PANEL. LINE UP WITH THE HOLE ON THE END PANEL AND ATTACH WITH 1/14" STEEL FLAT HEAD SCREWS FROM THE OUTSIDE. (SEE DIAGRAM "8B") PLACE THE TOP GLASS SUPPORT INTO THE FOOTPIECE AND ATTACH THE SUPPORT TO THE SLIDING DOOR TRACK WITH THE 1" STEEL FLAT HEAD SCREW. (SEE DIAGRAM "8C"). BEND BACK THE TABS OF THE FOOTPIECE INWARD USING PLIERS TO HELP HOLD THE SUPPORT INPLACE. (SEE DIAGRAM "8D")



JEWELRY SHOWCASE ASSEMBLY INSTRUCTION MANUAL

STEP 9:


ATTACH THE FOAM TAPE STRIPS TO THE TOP OF THE UPPER FRONT GLASS TRACK AND UPPER SLIDING DOOR TRACK NEXT TO THE LIPPED EDGE. (SEE DIAGRAM "9A")

COVER THE DONWTUBE HOLE WITH PLASTIC CAP. (SEE DIAGRAM "9B")

AFFIX THE COLORED STICKERS OVER SCREWS ON THE OUTSIDE FACE AND END PANELS (SEE DIAGRAM "9C")

INSTALL SLIDING DOOR PANELS BY LIFTING DOOR UP INTO TOP TRACK, THEN DROPPING DOWN INTO THE BOTTOM TRACK. (MAKE SURE THAT THE DOOR WITH THE PULL GOES ON THE LEFT GOES ON THE LEFT AND THE RIGHT GOES TO THE RIGHT. ALSO MAKE SURE EACH DOOR IS IN A SEPERATE TRACK GROOVE.)

(SEE DIAGRAM "9D")





SLIDING DOORS




NOTE:
USED RAZOR BLADE TO TRIM
FOAM TAPE AS NECESSARY

FOAM TAPE
STRIPS

SEE 9A



9B
INSIDE OF
SHOWCASE



JEWELRY SHOWCASE ASSEMBLY INSTRUCTION MANUAL

STEP 10:

CAREFULLY LOWER THE TOP GLASS AND PRESS FIRMLY INTO PLACE. YOUR UNIT IS NOW COMPLETE.

