


ASSEMBLY INSTRUCTIONS MANUAL
#70100 (OFF WHITE)
WOMAN'S JERSEY DRESSMAKER FORM




ASSEMBLY INSTRUCTIONS MANUAL

#70100 (OFF WHITE) WOMAN'S JERSEY DRESSMAKER FORM


PARTS IN CARTON:

OFF-WHITE
JERSEY DRESSMAKER FORM
(1 EACH)


NECK FINIAL
TOPPER
(1 EACH)




NECK FINIAL
(1 EACH)



BASE TOPPER
(1 EACH)




ADJUSTABLE POLE
(1 EACH)




BASE POST
(1 EACH)

LEG HOLDER BASE
(1 EACH)



LEGS
(3 EACH)




ASSEMBLY INSTRUCTIONS MANUAL

#70100 (OFF WHITE) WOMAN'S JERSEY DRESSMAKER FORM

STEP 1


SLIDE LEGS (3) INTO THE SLOTS OF THE LEG HOLDER BASE UNTIL TOP OF LEGS ARE FLUSH WITH TOP OF BASE.



LEG HOLDER BASE

STEP 2

SLIDE BASE TOPPER ONTO THE TOP OF BASE.




ASSEMBLY INSTRUCTIONS MANUAL

#70100 (OFF WHITE) WOMAN'S JERSEY DRESSMAKER FORM

STEP 3

SCREW THE BASE POST (CLOCK-WISE) ON TO THE BASE TOPPER UNTIL TIGHT.




ASSEMBLY INSTRUCTIONS MANUAL


#70100 (OFF WHITE) WOMAN'S JERSEY DRESSMAKER FORM

STEP 4

SCREW THE ADJUSTABLE POLE (CLOCK-WISE)
ON TO THE BASE TOPPER UNTIL TIGHT.




DRESSMAKER
FORM



ADJUSTABLE
POLE

STEP 5

ADJUST THE ADJUSTABLE POLE TO YOUR
DESIRED HEIGHT. SLIDE DRESSMAKER
FORM ON TO ADJUSTABLE POLE UNTIL
SECURE.



ASSEMBLY INSTRUCTIONS MANUAL

#70100 (OFF WHITE) WOMAN'S JERSEY DRESSMAKER FORM

STEP 6

SLIDE NECK FINIAL TOPPER THROUGH NECK FINIAL AND SCREW CLOCK-WISE INTO DRESSMAKER FORM UNTIL TIGHT.

THIS COMPLETES THE ASSEMBLY.

