


STANDING GRID SCREEN/GRID LEGS
ASSEMBLY INSTRUCTIONS


GRID LEGS



PARTS:
2- Legs
4- Bolts
4- Nuts
8- Lock Washers







NOTE: Grid Panel Has Double Wires on long-sides -- the grid-leg's bolts fit between these wires and attach to nut on inside of panel.