Female Jersey Dressmaker Form

ITEM #70190 | COLOR Black



BEFORE YOU BEGIN

STEPS
6 steps

PARTS
10 pieces, checklist on page 2

Need help?

Missing a part or have a question? We can help.

CALL
1-800-823-8887


EMAIL
contactus@storesupply.com

ONLINE
storesupply.com

MAIL
12955 Enterprise Way, Bridgeton, MO 63044

Scan to see this product online

Parts in the carton




Check the carton

Tick off each part before you start.

- ☐ **1 ×** Neck finial topper
- ☐ **1 ×** Neck finial
- ☐ **1 ×** Jersey dressmaker form
- ☐ **1 ×** Adjustable pole
- ☐ **1 ×** Base topper
- ☐ **1 ×** Base post
- ☐ **1 ×** Leg holder base
- ☐ **3 ×** Legs


STEP 1

Slide legs (3) into the slots of the leg holder base until top of legs are flush with top of base.




STEP 2

Slide base topper onto the top of base.




STEP 3

Screw the base post (clockwise) onto the base topper until tight.



STEP 4

Screw the adjustable pole (clockwise) onto the base topper until tight.




STEP 5

Adjust the adjustable pole to your desired height. Slide dressmaker form onto adjustable pole until secure.



STEP **6**

Slide neck finial topper through neck finial and screw clockwise into dressmaker form until tight.



Assembly complete

This completes the assembly.

